

TRIVAC[®] L D 40 L / D 63 L / D 90 L

Rotary Vane Vacuum Pump

Operating instructions 300956027_002_A1

Part Numbers

1019040V00/1019040V01/ 1019040V02/1019040V03

1019063V00/1019063V01/ 1019063V02/1019063V03

1019090V00/1019090V01/ 1019090V02/1019090V03

and their variants.



Copyright notice

©Leybold GmbH. All rights reserved.

Published: 11/14/2022

Trademark credit

Leybold and the Leybold logo are trademarks of Leybold GmbH, Bonner Strasse 498, D-50968 Cologne.

Disclaimer

The content of this manual may change from time to time without notice. We accept no liability for any errors that may appear in this manual nor do we make any expressed or implied warranties regarding the content. As far as practical we have ensured that the products have been designed and constructed to be safe and without risks when properly installed and used in accordance with their operating instructions.

We accept no liability for loss of profit, loss of market or any other indirect or consequential loss whatsoever.

Product warranty and limit of liability are dealt with in our standard terms and conditions of sale or negotiated contract under which this document is supplied.

You must use this product as described in this manual. Read the manual before you install, operate, or maintain the product.

Contents

1 8	Safety and compliance	7
1.1	Definition of Warnings and Cautions	7
1.2	Trained personnel	7
1.3	Safety symbols	. 8
2 I	mportant safety information	9
2.1	Mechanical hazards	9
2.2	Electrical hazards	10
2.3	Thermal hazards	10
2.4	Hazards caused by materials and substances	10
2.5	Danger of ignition	12
2.6	Hazards caused by noise	12
2.7	Risk of damage to the pump	12
3 [Description	14
3.1	Principle of operation	14
3.2	Lubricants and oil	15
3.3	Supplied equipment	15
4 1	Fechnical data	17
4.1	Dimension drawing	17
4.2	Performance curves	26
4.3	Material of construction	27
4.4	Ordering information	27
5 1	Fransportation	29
5.1	Transport and packaging	29
5.1.	1 Unpack	29
5.1.	2 Remove the pump	30
5.1.	3 Lift the pump	31
5.2	Mounting orientation	32
6 I	nstallation	34
6.1	Conforming utilisation	34
6.2	Non-conforming utilisation	34
63	Placement	35

Contents

6.4 Connection to the system	5
6.5 Installation drawing	7
6.6 Motor installation	8
6.7 Electrical connections	2
7 Operation 4	4
7.1 Media compatibility	4
7.2 Start-up	4
7.3 Operation	5
7.3.1 Pumping of non-condensable gases 4	5
7.3.2 Pumping of condensable gases and vapours 4	5
7.3.3 Operating temperature 4	7
7.3.4 Shut down	7
7.4 Ultimate pump pressure 4	8
7.5 Taking out of use	8
8 Maintenance 4	9
8.1 Safety information	.9
8.2 Maintenance intervals	.9
8.3 Maintenance work	3
8.3.1 Check the oil level	3
8.3.2 Check the oil condition	3
8.3.3 Change the oil	4
8.3.4 Clean or replace the oil sight glass 5	5
8.3.5 Clean the intake port dirt-trap and anti-suck back valve. 5	6
8.3.6 Check the coupling and coupling element 5	7
8.3.7 Replacement of electrical motor	8
8.3.8 Clean the motor cooling fan 5	9
8.4 Service	9
8.4.1 Return the equipment or components for service 5	9
8.5 Spare parts 6	Ю
9 Fault finding 6	2
10 Accessories 6	6
10.1 Oil mist filter	6
10.1.1 Technical data	7
10.1.2 Installation	7

Contents

10.1.3 Operation	
10.2 Maintenance of oil mist filter	
10.2.1 Spare parts	
10.2.2 Fault finding of oil mist filter	
10.3 Solenoid valve for gas ballast	
10.3.1 Technical data	
10.3.2 Installation	
10.3.3 Wiring connection	
10.4 Permanent gas ballast	
10.4.1 Installation	
11 Storage 77	
12 Disposal 78	
13 Legal declarations 79	

List of Figures

Figure 1. Section drawing of TRIVAC L
Figure 2. Dimension drawing - TRIVAC D 40 L
Figure 3. Dimension drawing - TRIVAC D 63 L
Figure 4. Dimension drawing - TRIVAC D 90 L
Figure 5. Dimension drawing - TRIVAC D 40 L . BS 20
Figure 6. Dimension drawing - TRIVAC D 63 L . BS
Figure 7. Dimension drawing - TRIVAC D 90 L . BS 22
Figure 8. Pumping speed curve - TRIVAC D 40 L 26
Figure 9. Pumping speed curve - TRIVAC D 63 L
Figure 10. Pumping speed curve - TRIVAC D 90 L
Figure 11. Installation drawing - TRIVAC D 40 L
Figure 12. Installation drawing - TRIVAC D 63 L
Figure 13. Installation drawing - TRIVAC D 90 L 37

Safety and compliance

1 Safety and compliance

For safe operation from the start, read these instructions carefully before you install or commission the equipment and keep them safe for future use. Read all the safety instructions in this section and the rest of this manual carefully and make sure that you obey these instructions.

1.1 Definition of Warnings and Cautions

Important safety information is highlighted as warning and caution instructions which are defined as follows. Different symbols are used according to the type of hazard.

WARNING:

If you do not obey a warning, there is a risk of injury or death.

CAUTION:

If you do not obey a caution, there is a risk of minor injury, damage to equipment, related equipment or process.

NOTICE:

Information about properties or instructions for an action which, if ignored, will cause damage to the equipment.

We reserve the right to change the design and the stated data. The illustrations are not binding.

1.2 Trained personnel

For the operation of this equipment "trained personnel" are:

- skilled workers with knowledge in the fields of mechanics, electrical engineering, pollution abatement and vacuum technology and
- personnel specially trained for the operation of vacuum pumps

Safety and compliance

1.3 Safety symbols

The safety symbols on the products show the areas where care and attention is necessary.

The safety symbols that we use on the product or in the product documentation have the following meanings:

	Warning/Caution An appropriate safety instruction must be followed or caution to a potential hazard exists.
	Warning - Automatic start up The equipment can be remotely started.
	Warning - Dangerous voltage Identifies possible hazards from hazardous voltages.
A	Warning - Heavy object Identifies a possible hazard from a heavy object.
	Warning - Hot surfaces Identifies a potential hazard from a hot surface.
A	Warning - Trip hazard There is a risk of slipping, tripping or falling as a result of spilled liquids, trailing cords and pipes or other low-lying objects.
	Warning - Wear hearing protection
<u>=</u>	Warning - Protective earth (ground) Earth point for electrical equipment.
	Warning - Risk of explosion There is a risk of explosion when you do the task.

2 Important safety information

2.1 Mechanical hazards

WARNING: BLOCKED EXHAUST

Risk of injury or damage to the equipment. If exhaust gases are collected or contained, the exhaust line may get pressurised. Make sure that the gas flow from the exhaust port is not blocked or restricted in any way.



The pressure in the oil box must not exceed 0.5 bar(g). An exhaust line too small in diameter or which is blocked can result in overpressure within the pump. The pump may get damaged or burst if the pump is opened. So the exhaust line must be checked from time to time to make sure that there are no obstructions.

Design the exhaust line so that the pressure does not reach above 1.15 bar absolute (0.15 bar relative). The pressure regulation device must be installed by the end-user. We recommend to treat the gases from the pump exhaust in function of their nature.

- Do not expose any part of the human body to the vacuum as this can cause injury.
- Do not step on the pump.
- Do not operate the pump without connecting the intake line or without fitting a blank flange.
- Do not open vacuum connections, oil filling plug and oil draining valve during operation of the pump as there is a risk of serious injury.
- The location at which the pump (including its accessories) is being operated must not have an angle more than 10 degrees from the vertical. Check that the inclination of the pump is less than 10 degrees from the vertical. Select the operating place so that all controls are easily accessible.
- Move the pump filled with oil only in its upright position. Spilt oil involves the risk of falling.
- Take adequate safety precautions before you open the intake or exhaust
- Do not connect the intake line of the pump to a device with over atmospheric pressure.
- Operating the pump without oil or operating with incorrect direction of rotation can damage the pump.
- Do not use discarded seals. Always assemble using new seals.
- Follow the instructions concerning environmental protection to discard used oil.
- Touch the inner sections of the pumps only while wearing clean gloves and use clean tools, do the necessary work in clean and dry rooms.
- Do not allow the ingestion of any objects for example-screws, welding beads, nuts, washers, pieces of wire, fittings etc. through the intake port of the pump. Objects falling into the pump can cause severe damage.
- To move the pump always use suitable transport means.

2.2 Electrical hazards

WARNING: HAZARDOUS VOLTAGES



Risk of electric shock. Do not touch parts at high electric voltages, there is the risk of suffering severe injuries by an electric shock. Covers marked with this symbol must only be opened by trained electricians after having reliably de-energised (Lockout/ Tagout) the equipment. Observe the national regulations for example - EN 50110-1 for Europe.

WARNING: AUTOMATIC RESTART



Risk of injury or damage to the equipment. After a mains power failure, the pump will operate automatically again. This also applies in the case of an emergency shutdown. To prevent the pump from operating automatically, the pump must be integrated with a control arrangement such that it can only be switched on manually after the mains power has returned.

- Always operate the pump with a properly connected protective earth conductor and make sure that the motor terminal box is closed.
- Lay electric feed lines so that there is no risk of tripping.
- Lay the connecting lines so that the connecting lines do not get damaged. Protect the lines against humidity and contact with fluids. Avoid thermally stressing the lines by unfavourable laying. Provide strain relief for the connecting lines so that the plugs and the line connectors are not subjected to excessively high mechanical stresses.
- Take appropriate precautions to make sure that the pump does not start while laying electric feed lines.

2.3 Thermal hazards



WARNING: HOT SURFACE

Risk of burn. During normal operation, the pump surface temperature can reach above 70 °C (158 °F). There is a risk of getting burns. Note the symbols on the pump indicating the hazards. If the pump is hot, wear the required protective clothing. All the work must be done using protection gloves if the pump is still warm.

- Handle the pump only after venting and after it cools down.
- Do not remove the oil-fill or oil-drain plugs while the pump is operating.
 There is a risk of suffering burns. Always wear protective gloves and protective goggles for protection against the oil.
- Note the warning information on the housing surface. If these warning notices have been removed, covered or obstructed, include corresponding additional warning information.

2.4 Hazards caused by materials and substances



WARNING: HAZARDOUS SUBSTANCES

Risk of injury. When pumping toxic, chemical, radioactive and corrosive gases as well as pyrophoric substances, you must comply with the national and international safety regulations and guidelines. If such gases or substances are to be pumped, consult us first for the suitability of the pumps for special applications.



WARNING: CONTAMINATION HAZARD

Risk of toxic exposure. Contaminated parts can be detrimental to health and the environment. Before beginning with any work, find out whether any parts are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.

- Liquid and solid particles or dust must not enter the pump. Install the adequate filters, separators and/or condensers. In case of doubt consult us.
- The pump must be packaged in such a way that it will not be damaged during shipping so that no harmful substances can escape from the package.
- The vacuum and exhaust lines must be leak tight. Hazardous process gases may escape or the pumped gases can react with air or atmospheric humidity. After installation of the pump and after servicing work on the vacuum system, leak detection is necessary. When pumping hazardous gases we recommend to do leak detection regularly. Leaks in the pump cannot be ruled out under all circumstances. When pumping hazardous gases, the operator must make sure that leaks at the pump and in the vacuum system will not be a hazard.
- Since all application related hazards for vacuum systems cannot be described in detail in these operating instructions, we have a separate document (safety booklet) available in which the hazards and general safety concepts for design, operation and maintenance of vacuum systems are explained.
 When planning to pump hazardous substances with this pump, read the related chapters in the safety booklet and these operating instructions first. You can download the safety booklet from our homepage.
- The pump is not suitable for oxygen pumping operation.
- Before commissioning the pump, make sure that the media which are to be pumped are compatible with each other to avoid hazardous situations. All relevant safety standards and regulations must be observed.
- If the pump has previously handled hazardous gases, implement the proper precautionary measures before opening the intake or exhaust connection. Before opening the pump, purge it for a longer period with an inert gas. If necessary, use gloves, a respirator and/or protective clothing and work under an exhaust hood. Firmly seal off the pump. When shipping the contaminated pump for servicing, also state the type of hazard. Refer to Service on page 59 for more details.
- When cleaning a system in which a pump has been integrated, all parts in contact with the medium need to be compatible with the cleaning agent to prevent a chemical reaction. Residues of the cleaning agent within the pump must be avoided.
- The pump is not suitable for operation in the explosion hazard areas.

2.5 Danger of ignition



WARNING: IGNITION HAZARD

Risk of injury or damage to the equipment. The pumps including the accessories are not suitable for pumping combustible and explosive gases or vapours.

2.6 Hazards caused by noise



CAUTION: NOISE HAZARD

Risk of injury. The noise level produced by the pump is less than or equal to 60 dB(A). Suitable hearing protection measures must be used while working.

2.7 Risk of damage to the pump

- Before starting up for the first time, the motor circuit must be equipped with a suitable protective motor switch. Take note of the information in these operating instructions and on the electric motor (wiring diagram).
- Do not allow the ingestion of small objects (screws, nuts, washers, pieces of wire, etc.) through the inlet port. So always use the inlet screen which is supplied as standard.
- Do not use the pump for applications that produce abrasive or adhesive powders or condensable vapours that can leave adhesive or high viscosity deposits. When planning to pump vapours other than water vapour, contact our sales or service department for advice.
- This pump is suitable for pumping water vapour within the specified water vapour tolerance limits.
- Avoid vapours that can condense into liquids when being compressed inside the pump, if these substances exceed the vapour tolerance of the pump.
- Before pumping vapours the pump must attain its operating temperature. It takes approximately 30 minutes for the pump to attain its operating temperature after the pump is started. During this warming up phase, the pump must be separated from the process, for example, by a blocking valve in the intake line.
- In the case of wet processes, we recommend the installation of liquid separators upstream and downstream of the pump as well as the use of the gas ballast.
- The exhaust line must be laid so that it slopes down and away from the pump to prevent condensate from backstreaming into the pump.
- The entry of particles and fluids must be avoided under all circumstances.
- Reactive or aggressive substances in the pump chamber may impair the operating oil or modify it. In addition, such substances may be incompatible with the materials of the pump (viton, grey cast iron, aluminium, steel, resins, glass etc.).
- Corrosion, deposits and cracking of oil within the pump are not allowed.
- Normal amounts of humidity within the range of the pump's water vapour tolerance will not significantly affect pump performance when the gas ballast is active.

- When operating the pump at gas throughput, it is recommended to connect an exhaust filter or use a suitable exhaust line. The exhaust line must slope down and away from the pump.
- In the case of custom pumps, note the information provided in the supplementary sheets.

Description

3 Description



WARNING: EXPLOSION HAZARD

Risk of injury and damage to the equipment. The pump must not be installed and operated within explosion hazard areas.

The TRIVAC L pumps are two-stage, oil sealed, sliding-vane vacuum pumps.

The pump is designed for pumping inert gases in the range of medium vacuum, between atmospheric pressure and the ultimate pressure of the pump. When removing condensable vapours, a gas ballast valve must be opened.

TRIVAC L pumps are capable of pumping gases, vapours and evacuating vessels or vacuum systems down into the medium vacuum range. The standard version of the pump is not suitable for pumping oxygen exceeding 25% and for pumping hazardous substances or aggressive or corrosive gases.

Through an intermediate flange, a four-pole three-phase motor is mounted to the coupling housing. The pump and motor shafts are directly connected by a flexible coupling. The oil-level glass, drain valve and nameplate are arranged on the same side. All vacuum connections are default on the top of the pump.

3.1 Principle of operation

The pump is an oil-sealed rotary vane pump. The anti-suck back valve, gas ballast valve and oil return circuit are integrated functional elements. The pump is driven by a directly flanged motor.

The rotor, mounted eccentrically in the pump housing, has two radially sliding vanes which divide the pump chamber into several compartments. The volume of each compartment changes periodically with the rotation of the rotor.

As a result, gas is sucked in at the intake port. The gas passes through a dirt trap sieve and open the anti-suck back valve, then enters the pump chamber. In the pump chamber, the gas is passed on and compressed after the inlet aperture is closed by the vane.

The oil injected into the pump chamber is used for sealing and lubricating. The slap noise of the oil in the pump which usually occurs when attaining the ultimate pressure is prevented by admitting a very small amount of air into the pump chamber.

The compressed gas in the pump chamber is ejected through the exhaust valve. The oil entrained in the gas is coarsely separated by the exhaust cover. There the oil is also freed of mechanical impurities. The gas leaves the pump through the exhaust port.


During compression, a controlled amount of air - the so-called gas ballast can be allowed to enter the pump chamber by opening the gas ballast valve. The gas ballast stops the condensation of vapours in the pump chamber up to the limit of the water vapour tolerance as specified in the technical data for the pump.

Description

The gas ballast valve is opened (position I and position II) and closed (position 0) by turning the gas ballast knob on the front.

A solenoid-operated gas ballast 24 V d.c. is available as an option to give automatic or remote control of gas ballast (refer to Accessories on page 66).

Figure 1. Section drawing of TRIVAC L



- 1. Intake port
- 3. Exhaust valve
- 5. 7. Pump chamber
- Rotor
- Anti-suck back valve
- Exhaust port
- 4. Exhaust channel
- 6. Vanes
- Intake channel

3.2 Lubricants and oil

The standard pumps are ready for operation with mineral oil.

For operating a pump we specify our vacuum pump oils which are supplied with the pumps.

Recommended oil: LEYBONOL LVO 130

For specific applications and pumping gas mixture, consult your local representative to select the right lubricant.

3.3 Supplied equipment

The equipment supplied with the pump includes:


- Pump with motor
- 1 centering ring DN 40 KF
- 1 centering ring DN 40 KF with dirt trap
- 2 clamping rings DN 40 KF
- Operating instructions or QR sheet to download it.
- Spare parts list.

Description

For protection during shipment, the connection ports are each blanked off by the blank flange. The pumps delivered from the factory are filled with oil given in Lubricants and oil on page 15.

4 Technical data


4.1 Dimension drawing



All dimensions are given in mm (inch).

1. Inlet port
3. Oil filling plug

- 5. Oil drain valve with female threads G1/2"
- Gas ballast
- * For variants with motor
- 2. Exhaust port
- 4. Oil sight glass
- Lifting lug^{*}




All dimensions are given in mm (inch).

1. Inlet port
3. Oil filling plug

- 5. Oil drain valve with female threads G1/2"
- Gas ballast
- * For variants with motor


- 2.
- Exhaust port Oil sight glass 4.
- Lifting lug*



All dimensions are given in mm (inch).


1. Inlet port

- Oil filling plug
- 3. 5. Oil drain valve with female threads G1/2"
- 7. Lifting lug*
- * For variants with motor
- 2. Exhaust port
- Oil sight glass 4.
- Gas ballast




All dimensions are given in mm (inch). 1. Motor

- 3. 5. Exhaust port
- Oil sight glass
- 7. Lifting lug*
- * For variants without motor
- 2. Inlet port
- 4. Oil filling plug
- Oil drain valve with female threads 6. G1/2"
- 8. Gas ballast



All dimensions are given in mm (inch). 1. Motor

- Exhaust port
- 3. 5. Oil sight glass
- Lifting lug*
- * For variants without motor
- 2. Inlet port
- 4.
- Oil filling plug Oil drain valve with female threads 6.
- 8. Gas ballast



All dimensions are given in mm (inch). 1. Motor

- 3. Exhaust port
- Oil sight glass
- Lifting lug*
- * For variants without motor
- 2. Inlet port
- 4. Oil filling plug
- Oil drain valve with female threads G1/2"
- 8. Gas ballast

Table 1 Technical data

Parameter	1111	TRIVAC D 40 L		TRIVAC D 63 L		TRIVAC D 90 L	
Parameter	Unit	50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz
	m ³ /h	49	59	67	80	92	110
Nominal pumping speed 1)	(cfm)	28.8	34.7	39.4	47.0	54.1	64.7
D	m ³ /h	42	50	60	72	79	95
Pumping speed ¹⁾	(cfm)	24.7	29.4	35.3	42.3	46.4	55.91
	mbar	3 x	10 ⁻³	3 >	· 10 ⁻³	3 >	< 10 ⁻³
Ultimate total pressure without gas ballast 1)	(Torr)	2.2	x 10 ⁻³	2.2	x 10 ⁻³	2.2	x 10 ⁻³
1)	mbar	6 x	10 ⁻³	6>	10 ⁻³	6 >	κ 10 ⁻³
Ultimate total pressure with gas ballast 1) OP1	(Torr)	4.5	x 10 ⁻³	4.5	x 10 ⁻³	4.5	x 10 ⁻³
4)	mbar	2 x	10-2	2 >	x 10 ⁻²	2 x 10 ⁻²	
Ultimate total pressure with gas ballast 1) OP2	(Torr)	1.5 x 10 ⁻²		1.5 x 10 ⁻²		1.5 x 10 ⁻²	
Western and a second selection of the selection of the second selection of the second selection of the second selection of the second selection of the sel	mbar	35		30		25	
Water vapour tolerance with gas ballast OP2	(Torr)	26.2		22.5		18.75	
Water vapour capacity 50/60 Hz	g/h	1090	1308	1334	1601	1464	1757
vvater vapour capacity 50/00 Hz	(lb/h)	2.40	2.88	2.94	3.52	3.22	3.87
Oil filling, minimum/maximum		3.1/4.1		3.3/4.4		3.6/4.8	
On mining, rim mindir, rite annum	(qt)	3.2/4.3		3.4/4.6		3.8/5.0	
Admissible ambient temperature	°C	10 ~ 40					
ramioside ambient temperature	(°F)	50 ~ 104					
Noise level without / with gas ballast ²⁾ OP1	dB(A)	58/60					
Dump dimensions /L v W v LI	mm	725 x 244 x 352		781 x 244 x 352		859 x 244 x 352	
Pump dimensions (L x W x H)	(inch)	28.5 x 9.6 x 13.8		30.7 x 9.6 x 13.8		33.8 x 9.6 x 13.8	
Pump dimensions without motor (L x W x H)	mm	568 x 2	44 x 352	598 x 244 x 352		684 x 244 x 352	
	(inch)	22.3 x 9.6 x 13.8		23.5 x 9.6 x 13.8		26.9 x 9.6 x 13.8	
Shipping dimensions (L x W x H)	mm		46 x 538	950 x 446 x 538		984 x 314 x 574	
Shipping difficiolotis (E X VV X LI)	(inch)	37.4 x 1	7.5 x 21.1	37.4 x 17.5 x 21.1		38.7 x 12.3 x 22.5	

Parameter	llmit	TRIVAC D 40 L		TRIVAC D 63 L		TRIVAC D 90 L					
Faiametei	Unit	50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz				
Net weight without oil	kg	66		66		66			72		83
Thet weight without oil	(lbs)	145.5		158.7		182.9					
Not weight without motor	kg	59		63		69					
Net weight without motor	(lbs)	130.0		138.8		152.1					
Total shipping weight	kg	78		84		96					
Total shipping weight	(lbs)	171.9		171.9 185.1		85.1	2	11.6			
Intake connection	-	DN 40 ISO-KF									
Exhaust connection	-	DN 40 ISO-KF									

¹⁾ For DIN 28400 and following numbers, with standard gas ballast.

Table 2 Unit conversion

	Different pressure units			Different pumping speed units				
Conversion factors	mbar (milli- bar)	torr	inches Hg vacuum		m ³ .h ⁻¹ (m ³ /h)	Is ⁻¹ (I/s)	cfm (cubic feet per minute)	
	1013	760	0	$m^3.h^{-1} = m^3/h$	1	0.278	0.589	
1 lb = 0.453 kg	400	300	18.12	Is ⁻¹ = I/s	3.60	1	2.12	
1 qt = 0.946 l	133	100	25.98	cfm = cubic feet per minute	1.699	0.472	1	
1 hp = 0.735 kW	4	3	29.80					
1 rpm = 1 min ⁻¹	1	0.75	29.89					
1 inch = 25.4 mm	0.1	0.075	29.92					
	1 atm (atmosp	ohere) = 101	3 bar	Example: $1 \text{ m}^3\text{h}^{-1} = 0.589 \text{ cfm}$			•	
1 Pa (pascal) = =0.01 mbar = 10 ⁻² mbar		Note: The nominal pumping speed of a pump at 60 Hz is 20% higher than at 50 Hz.						
1 bar = 1000 mbar								
	1 torr = 1.33 r	mbar						

²⁾ Operated at the ultimate pressure without/with gas ballast OP1, free-field measurement at a distance of 1 m.

Table 3 Electrical data (three-phase motors)

Pump	Nominal supply (V)	Frequency (Hz)	Power (kW)	Product number	
	220/230/380/400	50	1.1	1019040V00	
TD1) (A O D 40 I	220/230/380/400/415	50	1.1	1010040\/01	
TRIVAC D 40 L, LVO 130	230/460	60	1.3	1019040V01	
200 100	200	50	1.5	1010040\/00	
	200/380	60	1.5	1019040V02	
	220/230/380/400	50	1.5	1019063V00	
TD1) (A O D OO L	220/230/380/400/415	50	1.5	1019063V01	
TRIVAC D 63 L, LVO 130	230/460	60	1.8	1019003001	
LVO 100	200	200 50		1010060\/00	
	200/380	60	2.2	1019063V02	
	220/230/380/400	50	2.2	1019090V00	
	220/230/380/400/415	50	2.2	1010000\/01	
TRIVAC D 90 L, LVO 130	230/460	60	2.6	1019090V01	
	200	50	3.0	1010000\/00	
	200/380	60	3.0	1019090V02	


Table 4 Motor requirement


Pump	Motor mounting #	Number of poles	Power	Frequency	Shaft length	Shaft di- ameter	Key
			Kw	Hz	mm	mm	GB/T1096 Type A
TRIVAC D 40L,			1.1	50		Ø24	8x7x40
BS, LVO130			1.3	60	50		
TRIVAC D 63L,	B14	4	1.5	50	50	Ø24	9y7y40
BS, LVO130		7	1.8	60			8x7x40
TRIVAC D 90L,			2.2	50	60	<i>α</i> 00	0v7vE0
BS, LVO130			2.6	60	60	Ø28	8x7x50


[#] As per standard IEC-72

For additional information about motor requirement please contact us.

4.2 Performance curves







4.3 Material of construction

Table 5. Material of construction

Component	Material				
Cylinder/End plate	Cast iron				
Rotor	Alloy structure steel				
Coupling housing	Cast aluminium				
Mounting plate					
Oil casing					
End plate	Cast aluminium				
HV stop plate					
Exhaust cover					
Oil casing	Extrusion aluminium alloy				
Gasket	Polychloroprene rubber				
Casket	Styrene-Butadiene rubber				
O-ring, piston O-ring	Fluoroelastomer (FKM)				
Vane	Resistant epoxy resin and glass fabric				
Lip seals	Fluoroelastomer (FKM)				
Oil tubes	Stainless steel				
Gas ballast knob	Rubber				

4.4 Ordering information

Product	Part number
TRIVAC D 40 L, EU/CN, LVO 130	1019040V00
TRIVAC D 40 L, EU/US, LVO 130	1019040V01
TRIVAC D 40 L, JP/KR, LVO 130	1019040V02

Product	Part number
TRIVAC D 40 L, BS, LVO 130	1019040V03
TRIVAC D 63 L, EU/CN, LVO 130	1019063V00
TRIVAC D 63 L, EU/US, LVO 130	1019063V01
TRIVAC D 63 L, JP/KR, LVO 130	1019063V02
TRIVAC D 63 L, BS, LVO 130	1019063V03
TRIVAC D 90 L, EU/CN, LVO 130	1019090V00
TRIVAC D 90 L, EU/US, LVO 130	1019090V01
TRIVAC D 90 L, JP/KR, LVO 130	1019090V02
TRIVAC D 90 L, BS, LVO 130	1019090V03

For ordering information of Roots system, refer to the respective manual.

5 Transportation

5.1 Transport and packaging

The pump passes a rigorous operating test in our factory and is packaged to avoid transport damages.


Check the packaging on delivery for transport damages. The outer packaging is made of a wooden pallet and cardboard or wood top.

If the pump is damaged, notify the supplier and the carrier in writing within three days; state the item number of the pump together with the order number and the supplier's invoice number. Retain all packing materials for inspection. Do not use the pump if it is damaged.


Use a forklift to transport the pallet.

If possible transport the pump in its original packaging, if not available exercise due care.

For TRIVAC D 40 L and TRIVAC D 63 L



For TRIVAC D 90 L




5.1.1 Unpack

Wear gloves and protection glasses before you unpack the pump.


1. Cut the 3 plastic straps carefully.

2. Remove the cardboard top and inner reinforced cardboard belt or wood

For TRIVAC D 40 L and TRIVAC D 63 L



For TRIVAC D 90 L




5.1.2 Remove the pump

The pump is attached by screws. Remove the screws under the pallet using a 13 mm wrench.

The pump is then ready to be shifted or lifted off the pallet.

Recycle or dispose of the packing materials according to environmental laws.



5.1.3 Lift the pump

WARNING: SUSPENDED LOAD



Risk of physical injury. Due to the pump weight, use only a suitable lifting device to lift the pump at the lifting lug (CE regulations). Lifting facilities are the only recommended way of handling the pump. Do not lift at the motor, cables connection boxes, flanges etc. Do not drag the pump from these points.

When you connect or remove the pump, do not move under hoisted loads. Fasten eye bolts only hand-tight. Eye bolts must be screwed in properly with full contact to the pump surface. Mounted eye bolts are only suitable for lifting the respective pump. They must not be used for other loads. Eye bolts must only be used in accordance with the conforming utilisations. Use eye bolts only with appropriate lifting devices.


Pumps that are filled with oil must only be moved while standing upright. Otherwise, the oil may escape. Avoid any other orientations while lifting.

The connection ports are blanked off by a blank flange.


Take the blank flange away before switching on the pump.

The pumps have their oil filled in.

For TRIVAC D 40 L and TRIVAC D 63 L



For TRIVAC D 90 L



5.2 Mounting orientation



CAUTION: TRIP HAZARD

Hazard of slipping, tripping or falling due to oil leakage from the pump. Check the pump for the presence of any oil leaks. There is a risk of falling due to oil spills. Take appropriate safety measures.

- Make sure that all safety regulations are observed.
- Use suitable lifting equipment according to the pump weight.

- Check the nameplate. Do not use pump elements other than the lifting lugs as handles.
- Only use the lifting lugs which are provided on the pump to lift the pump with the specified lifting devices.
- Refer to the *Installation drawing* on page 37 for the space required to install the pump.
- A pump that has been filled with oil must only be moved in the upright position (horizontally). Otherwise, the oil may escape.
- The angle of the slope must not be more than 10 degrees.
- Avoid any other orientations while you move the pump.

Installation

6 Installation



WARNING: HAZARDOUS VOLTAGE

Risk of shock. Before you install the pump make sure that the pump is reliably disconnected from the electrical power supply and prevent the pump from operating inadvertently.



CAUTION: PUMP DAMAGE

Risk of damage to the equipment. Do not stand on the pump and place objects on the pump as these can cause deformation of the pump.



Before conducting any kind of assembly work the personnel must be informed about potential hazards. Observe the safety information given in *Important safety information* on page 9.

Observe the following instructions step by step for the safe start-up.

6.1 Conforming utilisation

The pumps can pump gases and vapours and evacuate vessels or vacuum systems in the fine vacuum range.

The pumps are suitable for pumping water vapour within the specified water vapour tolerance limits. Avoid vapours that can condense into liquids when being compressed inside the pump, if these substances exceed the vapour tolerance of the pump. In the case of wet processes, we recommend the installation of liquid separators upstream and downstream of the pump.

6.2 Non-conforming utilisation

WARNING: HAZARDOUS SUBSTANCES



Risk of injury or damage to the equipment. The pump is not suited for pumping of:

- -radioactive and toxic substances
- -pyrophoric substances
- -corrosive gases
- -oxygen (or other highly reactive gases) at concentrations exceeding that of the atmosphere (> 21% for oxygen).

CAUTION: MAINTENANCE SAFETY



Risk of damage to the pump. The standard pump is not suited for pumping hazardous gases or vapours. When cleaning a system in which the pump has been integrated, all parts in contact with the medium must be compatible with the cleaning agent so as to prevent a chemical reaction. Residues of the cleaning agent within the pump must be avoided.

■ Note:

The pumps are not suited for pumping liquids or media which carry large quantities of dust. Corresponding protection devices need to be provided.

Installation

6.3 Placement



CAUTION: TOPPLING HAZARD

Risk of toppling. The maximum tilt allowed for the pump is 10 degrees from the vertical. To firmly install the pump in place, insert bolts through bore holes (Ø 8 mm) in the rubber feet.

■ Note:

The rubber feet act as vibration absorbers. They must therefore not be compressed by screws.

Set the pump on a flat, horizontal surface. Rubber feet under the coupling housing ensure that the pump cannot slip.

The installation site chosen must have ready accessibility to connections and controls of the pump.

Make sure that there is adequate cooling of the pump, leave sufficient space at the air intake and the exhaust points for cooling and give access for maintenance. Make sure to keep the air intake clear for the motor.

Make sure to keep the fans, hoods and air intake of the motor clean. The pump must be kept clean (no dust deposit). Install the pump such that the oil level sight-glass can be easily read and will not be broken.

The site chosen must allow adequate air circulation to cool the pump (keep front and rear unobstructed).

Note the ambient conditions during operation. The ambient temperature must not exceed +40 $^{\circ}$ C (104 $^{\circ}$ F) and not drop below +10 $^{\circ}$ C (50 $^{\circ}$ F) (refer to).

For installation sites 1000 m above mean sea level or relative atmospheric humidity of over 90%, you must discuss this with technical sales.

The maximum amount of heat given off approximately corresponds to the rated motor power.

Install the pump such that only minimal quantities of dust can deposit on the surfaces. In those cases where dust deposits form, measures need to be introduced which make sure that these are removed regularly.

The maximum gas inlet temperature must not exceed 80 °C.

The maximum pressure at the inlet must not exceed atmospheric pressure (approximately 1013 mbar). Do not apply overpressure to the pump's inlet. The maximum exhaust pressure must not exceed 0.5 bar(g).

6.4 Connection to the system

WARNING: EXHAUST EMISSION HAZARD



Risk of injury. Safely lead the exhaust gases away. Exhaust gases, depending on the type of application, may present a health hazard and/or may be detrimental to the environment.

The exhaust gases from the vacuum pump must be safely led away and subjected to post-treatment as required. To reduce the emission of oil vapours we recommend the installation of an additional exhaust filter (refer to *Accessories* on page 66). Depending on the type of application or the kind of pumped media, the corresponding regulations and information sheets must be observed.

Installation

CAUTION: EXHAUST PIPELINE BLOCKAGE

Risk of damage to the equipment. Note the specified cross sections for the connection lines.



If exhaust gases must be collected or contained, do not allow the exhaust line to become pressurised. The pressure in the oil box must not exceed 0.5 bar(g). An exhaust line that is too small in diameter or which is blocked can result in the formation of overpressure within the pump. Possible consequences can be a damaged or even burst open pump. Thus the exhaust line must be checked from time to time to ensure that there are no obstructions.

Do not operate the pump with a sealed exhaust line. There is the danger of injury.

Note:

To avoid back flowing condensate, install the exhaust line with a downward slope (lower than the pump) to prevent condensate from flowing back into the pump. If this is not possible, insert a condensate trap.

When oil mist is to be removed from the exhaust flow we recommend the use of the exhaust filter with lubricant return which is part of the pump system.

Before connecting the pump, remove the shipping seals from the connection flanges.

Retain the shipping seals in case you need to store the pump in the future.

The pump is shipped with intake and exhaust flanges mounted for vertical connection. You can easily convert the exhaust flange for horizontal connection. Connect the intake and exhaust lines with a centering ring and a clamping ring each. Use the centering ring with a dirt trap for the intake port.

Connect the intake and exhaust line using anti-vibration bellows, without placing any strain on the pump.

The maximum intake pressure must not exceed atmospheric pressure (1013 mbar).

The intake line must be clean. Deposits in the intake line may outgas and adversely affect the vacuum. The connecting flanges must be clean and undamaged.

The maximum throughput of the pump is equivalent to the pumping speed of the pump (refer to *Technical data* on page 17).

The cross-section of the intake line must be at least the same as that for the intake port. If the intake line is too narrow, it reduces the pumping speed. If the process gas contains dust, it is essential to install a dust filter in addition to the dirt trap supplied.


The dust filter is recommended to be installed horizontally. This makes sure that when you remove the filter, no particles fall into the intake port.

The pump may be operated with an inert gas ballast via a connection that is provided for this purpose. The gas ballast valve body can be replaced by a permanent or EM gas ballast valve with DN 16 KF connection. Matching connectors are available (refer to *Accessories* on page 66).

Gas ballast inlet pressure must not be more than 1013 mbar (absolute), and gas flow must be sufficient.

6.5 Installation drawing


Figure 11. Installation drawing - TRIVAC D 40 L



All dimensions given are in mm (inch). A. Cooling air - motor

B. Cooling air - pump


Figure 12. Installation drawing - TRIVAC D 63 L



All dimensions given are in mm (inch). A. Space for the motor ventilation

- C. Cooling air pump
- B. Space for pump ventilation
- D. Cooling air motor

Figure 13. Installation drawing - TRIVAC D 90 L




All dimensions given are in mm (inch). A. Space for the motor ventilation

- C. Cooling air pump
- B. Space for pump ventilation
- D. Cooling air motor


^{*} For bare shaft variants, please reserve the identical installation space for enough cooling air flow.

6.6 Motor installation

1. Disassemble nuts and washers as shown in figure.




- Nut M10
- WASHER ISO 7089-10
- 2. Remove the mounting plate.




Mounting plate

3. Install the flange on the flange surface of the motor and note that the direction of the arrow is consistent with the direction of the motor junction box. Take screws M8x25 from plastic bag in package box of pump. Install the screws with diagonal installation principle and tighten them with 20 Nm.




- 1. Flange
- 2. SCREW M 8 X 25
- 4. Remove the original jack screw from coupling unit.




1. Jack screw

5. Install the coupling on motor shaft as shown in figure.




- 1. Coupling
- 6. Apply LOCTITE 243 on the jack screw surface, install it to the coupling unit and tighten it.




1. Hexagon wrench 3 mm


7. Install the elastomer on coupling.



- Elastomer
- 8. Lift the motor with the help of eye bolt as marked in figure, align the pump bracket and install it.



Eye bolt



9. Tighten the nuts with washers and torque them with 35 Nm.

Nut M16

Make sure the pump pass the safety test after motor assembled.

After wiring connection do a trial run of motor to check if there is any abnormal noise.

6.7 Electrical connections



WARNING: PROTECTIVE EARTH CONNECTION

Risk of injury or damage to the equipment. The pump must be adequately earthed to prevent the accumulation of static electricity. The electrical junction box must only be opened and electrical connections made when no explosive atmosphere is present.

WARNING: DANGEROUS VOLTAGE



Risk of shock. The electrical connections must only be provided by a trained electrician as specified, for example, by the regulations EN 50110-1. Note the national regulations of the country in which the equipment is being operated.

During all connection work, the mains power supply lines must be de-energised (Lockout/Tagout). To prevent the pump from operating unexpectedly after a mains power failure, the pump must be integrated with the control system in such a way that the pump can only be switched on again manually. This applies equally to the emergency cut-out arrangements. Observe safety information given in *Electrical* hazards on page 10.

CAUTION: DAMAGE TO THE PUMP



Risk of damage to the equipment. Observe the direction arrow on the motor fan cover. It is recommended to check the direction of rotation with a phase sequence indicator.

Prolonged operating of the motor in the wrong direction of rotation will damage the pump.

In the case of custom pumps note the information provided on a separate sheet.

For connecting the motor, follow the schematics provided on the motor nameplate or in its junction box, given your local mains voltage and frequency. Electrical connection work must only be carried out by a qualified electrician in accordance with the applicable safety rules, see IEC 60204-1 and 61010-1.

The pump is supplied with a three-phase motor but without accessories for electrical connection. They must be connected with the appropriate cable and a suitable motor protection switch.

Set the switch in accordance with the rating on the motor nameplate. Observe the diagram at the motor.

After connecting the motor and after every time you alter the wiring, check the direction of rotation. To do so, briefly switch on the motor and check whether a suitable cover (for example- a blank flange) is sucked in at the intake port. If not, interchange two phases of the connection.

For motor wiring information, refer to the motor nameplate or the cover of the motor terminal box. You can configure the dual voltage motors to operate with either the high range or the low range electrical supply.

To reverse operating invert L1 and L2.

7 Operation

WARNING: OPERATION SAFETY



Risk of damage to the equipment. Do not start the pump more than six times within one hour to prevent the overloading of the motor. If frequent starts are needed, the pump must operate continuously and be linked to the vacuum vessel using a valve. In that case, regulation will be made by the valve and not by the start/stop of the pump. With the valve closed, the pump consumes less energy.

WARNING: HOT SURFACE

Risk of burns. The pump in operation is hot and some surfaces could reach a temperature higher than 80°C (176°F). There is a risk of burn by touching. Take note of warning labels on the pump. Let the pump cool down before you start any work.



WARNING: HAZARDOUS WORKING CONDITIONS

Risk of injury. Wear ear protection in case of operation at high inlet pressure.

7.1 Media compatibility

Pumps can pump condensable gases and vapours, provided that the gas ballast valve is open and the pump has attained its operating temperature.

7.2 Start-up



WARNING: AUTOMATIC RESTART

Risk of injury or damage to the equipment. To prevent the pump from operating unexpectedly after a mains power failure, the pump must be integrated with the control system in such a way that the pump can only be switched on again manually. This applies equally to emergency cut-out arrangements.



WARNING: OPERATION SAFETY

Risk of injury or damage to the pump. Before starting the pump make sure that the pump and the fitted accessories meet the requirements of your application and that safe operation can be guaranteed.



WARNING: VACUUM HAZARD

Risk of exposure to the vacuum. Do not operate the pump with an open intake port. Vacuum connections, oil feed and discharge openings must not be opened while the pump is operating. Avoid exposing any part of the human body to the vacuum. There is the risk of suffering injury. Observe safety information given in Mechanical hazards.



The pump is delivered filled with oil. Before you switch on the pump, make sure that the pump contains enough oil. The normal oil level in a standstill pump is in the upper half of the sight glass. Each time before you start up check the oil level. Do not operate the pump with an oil level below the minimum. To add the oil, unscrew the oil-fill plug, add oil and screw the plug firmly back in.

Open all valves blocking the exhaust lines. Do not operate the pump with a blocked or constricted exhaust line.

Check the direction of rotation before starting the pump for the first time and after each change in the electrical connection (refer to *Electrical connections* on page 42).

On initial start-up, after prolonged idle periods or after an oil change, the specified ultimate pressure cannot be attained until the oil is degassed.

This can be done by operating the pump for approximately 30 minutes with the intake line closed and the gas ballast valve open.

7.3 Operation

■ Note:

The pump can pump condensable gases and vapours, provided that the gas ballast valve is open and the pump has attained its operating temperature.


If exhaust gases must be collected or contained, do not allow the exhaust line to become pressurised. The pressure in the oil box must not exceed 0.5 bar(g). An exhaust line that is too small in diameter or which is blocked can result in the formation of overpressure within the pump. The pump may get damaged or burst if the pump is opened. Thus the exhaust line must be checked from time to time to make sure that there are no obstructions.

7.3.1 Pumping of non-condensable gases

If the process contains mainly dry gases, the pump may be operated without gas ballast (position 0), provided that the saturation vapour pressure at operating temperature is not exceeded during compression.

If the composition of the mixture to be pumped is not known and if condensation in the pump cannot be ruled out, operate the pump with dry air or dry inert gas ballast (position I or II) in accordance with Pumping of condensable gases and vapours.

7.3.2 Pumping of condensable gases and vapours



1. Gas ballast valve

2. Oil return port

The pump is equipped with a three-position manual gas ballast valve which operates with air.

The gas ballast is operated manually by turning the rubber knob on the gas ballast head. There are 3 positions:

- 0 closed (to achieve best ultimate pressure)
- I standard flow for standard vapour load
- II high flow for high vapour load (hydro mode)

The gas ballast flow is valid for a pump operating at ultimate pressure (inlet closed) and for a gas ballast gas supply of 1 bar (absolute). Above 1 bar (absolute) the pump may get damaged.

To operate the gas ballast with inert gas, remove the standard gas ballast and install the 'permanent gas ballast kits' with DN 16 KF connection available as an accessory. Refer to *Accessories* on page 66. For remote control, fit an EM gas ballast valve kit (available as an accessory, refer to *Accessories* on page 66). The EM gas ballast valve must be supplied with 24 V d.c.

The pump is slightly louder if the gas ballast valve is open. With the gas ballast valve open (position I or II) and when the temperature is stabilised, the pump can pump pure water vapour up to the water vapour tolerance specified in the technical data. If the vapour pressure increases above the permissible level, the water vapour will condense in the oil of the pump.

When pumping vapours make sure that the gas ballast valve is open and that the pump has been warmed up for approximately 30 minutes with the intake line closed.

Note:

Vapour phases may only be pumped up to the permissible limit after the pump has attained its operating temperature.

During pumping, vapours may dissolve in the oil. This changes the oil properties and thus there is a risk of corrosion in the pump. Therefore, do not switch off the pump immediately after the completion of the process. Instead, allow the pump to continue operating with the gas ballast valve open and the intake line closed until the oil is free of condensed vapours. We recommend operating the pump in this mode for about 30 minutes after completion of the process.

For processes with a high proportion of condensable vapours, the intake line must be opened slowly only after the pump has reached the operating temperature.

One sign of condensation of vapours in the pump is a rise of the oil level during the operation of the pump.

In cyclic operation, the pump must not be switched off during the intervals between the individual working phases (power consumption is minimal when the pump is operating at ultimate pressure) but must continue to run with the gas ballast valve open and intake port closed (if possible via a valve).

Once all vapours have been pumped off from a process (for example, during drying), the gas ballast valve can be closed to improve the attainable ultimate pressure.

Cap for gas ballast should not be removed, oil return from oil mist filter must be connected to oil return port.

7.3.3 Operating temperature



CAUTION: HOT SURFACES

Risk of injury. There is the danger of receiving burns. Observe safety information given in *Thermal hazards* on page 10.

Proper operation of the pump is ensured in the ambient temperature range between 10 $^{\circ}$ C to 40 $^{\circ}$ C (55 $^{\circ}$ F to 104 $^{\circ}$ F).

At operating temperature, the surface temperature of the pump can be higher than 70 °C (156 °F).

If due to the ambient conditions this temperature range is to be exceeded at either end of the range, contact us.

The motor may accelerate with a delay when simultaneously an undervoltage is present at the motor and the pump is at the minimum permissible and ambient temperature.

Under such operating conditions the motor protection switch may respond. In this case, the motor may be started again.

7.3.4 Shut down



CAUTION: OPERATION SAFETY

Risk of damage to the equipment. When pumping condensable media let the pump continue to operate with the gas ballast valve open and the intake line closed before switching off (refer to Pumping of condensable gases and vapours).

Under normal circumstances, switch off the pump. The intake port of the pump contains an anti-suck back valve which closes the intake port when the pump is shut down to prevent the pump oil from being sucked back into the vacuum chamber. The function of the valve is not impaired by gas ballasting. The anti-suck back valve is not a safety vacuum valve.

If the pump was exposed to aggressive and corrosive media, we recommend that you let the pump continue to operate even during long non-working intervals (for example, overnight) with the intake line closed and the gas ballast valve open. This avoids corrosion during idle periods and difficulties when re-starting the pump under conditions where the lubricant has been chemically modified.

If the pump operating with mineral oil is to be shut down for an extended period after pumping aggressive or corrosive media or if the pump has to be stored, proceed as follows:

- Pump and operating agents may be contaminated.
- If hazardous substances have been pumped, then these substances can escape from the pump and the oil. Introduce adequate safety precautions. Use gloves, face protection or a respirator, for example.
- Observe safety Information Hazards caused by materials and substances on page 10.
- Drain the oil (refer to *Change the oil* on page 54).
- Add clean oil until the oil level is at the "min" mark and let the pump operate for some time.
- Then drain the oil and add clean oil until the oil level is at the "max" mark.

- Seal the connection ports. Special conservation or anti-corrosion oils are not necessary.
- Also, take note of the information given in Transportation on page 29 and Storage on page 77.

7.4 Ultimate pump pressure

If the system cannot produce the pressures specified in the technical data, measure the ultimate pressure directly at the intake port of the pump after you disconnect the pump from the system. The ultimate partial pressure of non-condensable gases can only be measured with a compression vacuum gauge or a partial pressure gauge. Precise measurements can only be obtained with calibrated instruments.

Upon initial start-up, after prolonged idle periods or after an oil change, it takes some time until the pump reaches the specified ultimate pressure. Wait until a stable pump temperature is reached and be sure the pump oil is degassed. It takes approximately 30 minutes. We recommend operating the pump initially with the gas ballast valve open.

The ultimate pressure depends on the pump temperature and the pump oil used. The best ultimate pressures can be obtained at a low pump temperature by using the recommended oil types.

7.5 Taking out of use

Contact us for all the queries about the disposal of spares, consumables or the entire pump.

8 Maintenance

8.1 Safety information

WARNING: DANGEROUS VOLTAGES



Risk of electric shock. The electrical connections must only be provided by a trained electrician as specified, for example, by the regulations EN 50110-1. Note the national regulations of the country in which the equipment is being operated.

Disconnect the electrical connections before disassembling the pump. Make sure that the pump cannot be accidentally started.

Observe the safety information given in *Electrical hazards* on page 10.

WARNING: HAZARDOUS SUBSTANCES



Risk of injury or damage to the equipment. Make sure that there is no potentially explosive atmosphere before conducting any maintenance work.

If the pump has pumped harmful substances, contrary to what has been stated in *Principle of operation* on page 14, ascertain the nature of hazard and take adequate safety measures. Observe the safety information given *Hazards caused by materials and substances* on page 10.

When disposing of used oil, you must observe the applicable environmental regulations.

All work must be carried out by suitably trained personnel. Maintenance or repairs carried out incorrectly will affect the life and performance of the pump and will void any warranty claims.

Note:

Due to the design concept, the pumps require very little maintenance when operated under normal conditions. The maintenance required is described in the sections below. In addition to this, a maintenance plan is provided in *Maintenance intervals* on page 49.

We offer practical courses on the maintenance, repair and testing of pumps. Further details are available on request.

If the pump is used in ambient air which is contaminated, make sure that the air circulation and the gas ballast valve are not adversely affected.

When the pump has been pumping corrosive media we recommend that possibly planned maintenance work be carried out immediately to prevent corrosion of the pump while it is at standstill.

In case of special designs and variants always indicate the serial number.

8.2 Maintenance intervals

■ Note:

The intervals stated in the maintenance schedule are approximate values for normal pump operation. Unfavourable ambient conditions and/or aggressive media may significantly reduce maintenance intervals.

Table 6 Maintenance interval

TRIVAC D 40 L, TRIVAC D 63 L, TRIVAC D 90 L	Measurement / Test quantity Operation / Auxiliary materials	Interval	Remarks
Operate the pump for at least 1 hour with gas ballast.		Daily	Condensed water is thus removed from the oil
Check the oil level, change the oil if required.	Oil: LVO 130 or special and alternative oils refer to <i>Lubricants and oil</i> on page 15.	Daily, before switching on the system	Refill: Only after the pump has been switched off. Refer Check the oil level on page 53.
	Visually (all oils)	Weekly	Normally the oil is light and transparent, oil change is required when discolourations increase. Refer to <i>Check the oil condition</i> on page 53.
Check the quality of the oil, change the oil if required.	Chemically	6 months	According to DIN 51558, when the neutralisation number exceeds 2; then an oil change will be required. Refer to Check the oil condition on page 53.
	Mechanically	6 months	When the viscosity is 20% above the one of fresh oil; then an oil change will be required. Refer to <i>Check the oil condition</i> on page 53.
Change the oil	Oil: LVO 130	6 months	Oil change: • First oil change after 100 to 500 operating hours. • Pump switched off and cold. Change the oil while the pump is cold to avoid releasing adsorbed gases. Refer to <i>Change the oil</i> on page 54. Quantity of oil: Refer to .

TRIVAC D 40 L, TRIVAC D 63 L, TRIVAC D 90 L	Measurement / Test quantity Operation / Auxiliary materials	Interval	Remarks
Clean the oil level glass.	Suitable cleaning agent and compressed air.	Annually*	Clean the oil level glass with a cleaning agent and blow it out with compressed air under a suction hood. Use cleaning agents only corresponding to the national/international specifications. Observe the safety regulations when using cleaning agents Refer to Clean or replace the oil sight glass on page 55.
Clean the intake dirt trap and anti-suck back valve in the intake port. Change them as required.	Suitable cleaning agent and compressed air.	6 month	 Clean intake dirt trap with a cleaning agent and blow it out with compressed air under a suction hood. Replace the defective intake dirt trap. Clean the anti-suck back valve with a cleaning agent and dry it. Use a cleaning agent which complies with the national/international specifications. Observe the safety regulations when using cleaning agents Refer to Clean the intake port dirt-trap and anti-suck back valve on page 56.

TRIVAC D 40 L, TRIVAC D 63 L, TRIVAC D 90 L	Measurement / Test quantity Operation / Auxiliary materials	Interval	Remarks
Check the edges of the teeth on the coupling element for any damages, change the coupling element as required.		Annually*	Refer to Replacement of electrical motor on page 58 and Check the coupling and coupling element on page 57.
Check the fan of the motor as well as the cooling fins on the motor for deposits, and clean as required.	Brush and industrial vacuum cleaner.	Annually*	Clean before the maintenance interval has elapsed when the pump or the motor gets too warm. Caution: Switch off the pump and make sure that it does not run inadvertently (disconnect from the mains). Refer to Clean the motor cooling fan on page 59.

^{*} For normal applications, the maintenance interval is 1 year or 6000 hours.

The recommendation above is only for pumps running in normal applications. In case of running in medium and harsh applications, the maintenance interval needs to be shortened according to application requirements.

If other type of oil is used for the pump, the maintenance interval needs to be adjusted accordingly.

We recommend that you service the pump every three years covering the following:

- Cleaning
- Checking the individual components
- Exchange of all seals
- Functional check.

This service must be run by the our Service.

8.3 Maintenance work

Depending on the process involved, dangerous substances may escape from the pump and oil. Take the appropriate precautions. Observe safety regulations.

Do not install used seals. Always use new seals. Use only genuine parts provided by us.

8.3.1 Check the oil level



CAUTION: MAINTENANCE SAFETY

Risk of damage to the equipment. Check and top up oil only after having shut down the pump first. Note the safety information given in *Thermal hazards* on page 10 and *Hazards caused by materials and substances* on page 10.

During the operation of the pump, the oil level must always remain between marks on the oil-level glass. Refer to *Table: Maintenance interval*. The amount of oil must be checked and topped up as required.

The oil level must be checked at least once a day. Stop the pump and fill oil when needed.

Pumps that are not directly delivered from us, for example- in systems, may have been filled with oils different from recommended oil.Refer to *Lubricants and oil* on page 15. In this case, a refilling with recommended oil may cause problems. Therefore check the oil type before refilling and fill in or change the oil with suitable oil.

Overfilling leads to oil losses at high intake pressures. High oil consumption often indicates that exhaust filters are clogged.

8.3.2 Check the oil condition

The ageing process for the standard operating fluid (refer to *Lubricants and oil* on page 15) will depend very much on the area of application for the pump.

There exist the following ways of checking the oil condition:

- 1. Visual check: Normally the oil is clear and transparent. If the oil darkens, it must be changed.
- 2. Chemical check: The neutralisation number of oil is determined according to DIN 51558. If it exceeds 2, the oil must be changed.
- 3. Viscosity check: If the viscosity of LVO 130 at 25 °C exceeds a level of 240 mPas (20% higher than the viscosity of fresh oil) an oil change is recommended.

If gases or liquids dissolved in the oil result in a deterioration of the ultimate pressure, the oil can be degassed by allowing the pump to operate for approximately 30 minutes with the intake port closed and the gas ballast valve open.

When checking the oil, switch off the pump first and drain out the required amount of oil through the oil drain valve from the warm pump into a beaker or similar container.

Note the maintenance safety information given in Safety information on page 49.

8.3.3 Change the oil

WARNING: HAZARDOUS SUBSTANCES



Risk of injury or damage to the pump. Hazardous substances may escape from the pump and the oil. If there is a danger that the operating agent may present a hazard in any way due to decomposition of the oil or because of the media which have been pumped, you must determine the kind of hazard and make sure that all necessary safety precautions are taken. Use gloves, face protection or a respirator, for example.

Observe safety information given in *Thermal hazards* on page 10 and *Hazards* caused by materials and substances on page 10.

Change the oil while the pump is cold to avoid releasing adsorbed gases. If releasing adsorbed gases has no problem, change the oil after the pump has been switched off and while the pump is still warm.



WARNING: HOT SURFACE

Risk of burn. With the pump warm from the operation, both pump and oil can get so hot that there is the risk of suffering burns. If required, wear gloves.

Note:

Check and top up oil only after the pump has been shut down.

When disposing of waste oil, observe the applicable environmental protection regulations.


When changing the oil use the same type of oil which was previously in the pump. If you want to change the type of oil entirely consult us first.

The oil must be changed after the first 500 operating hours and then at least every 2000 - 3000 operating hours or after 6 months. At high intake pressures and/or high intake temperatures when pumping contaminated gases, the oil will have to be changed more frequently.

Further oil changes must be made before and after the long-term storage of the pump.

If the oil becomes contaminated too quickly, install a dust filter (refer to *Accessories* on page 66).

Contact us for more information on this matter.



- 1. Oil drain valve
- 3. Oil level mark minimum
- 5. Oil filling plug

- 2. Temperature switch port
- 4. Oil level mark maximum

Required tools:

Allen key 12 mm.

To change the oil do the procedure as follows:

- Open the oil-drain valve and drain the used oil into a suitable container.
- When the oil flow slows down, close the oil-drain valve, switch on the pump (for maximum 10 seconds) and switch it off. Drain the remaining oil.
- Close the oil drain valve, unscrew the oil-fill plug and fill the oil in the pump to meet the oil level requirement. Then screw the oil filling plug.
- In case of severe pollution, the pump should be flushed by filling with fresh oil up to the bottom edge of the oil-level glass, operate the pump for a short time and then change the oil again.
- When disposing of used oil, observe the relevant environmental regulations.


Note:

We can only guarantee that the pump operates as specified in the technical data if the lubricants recommended by us are used.

8.3.4 Clean or replace the oil sight glass

An oil sight glass is assembled in the oil casing end plate, which will indicate the oil level. If the oil sight glass is dirty, the user will not see the oil level directly and miss to refill the oil to meet the requirement. Clean or replace the oil sight glass if needed.

Figure: Clean or replace the oil



- 1. O-ring
- Gasket
- Screws

- 2. Glass
- 4. Glass bracket

Required tools: Allen key 3 mm

To clean or replace the oil sight glass do the procedure as follows:

- 1. Use the Allen key to remove 6 screws.
- 2. Remove the oil sight glass bracket, gasket, glass and O-ring.
- 3. Replace the used parts if necessary.
- 4. Re-assemble the oil sight glass in the reverse sequence.

Refer to Table: Oil sight glass kit for more information.

8.3.5 Clean the intake port dirt-trap and anti-suck back valve


A wire-mesh screen is located in the intake port of the pump to act as a dirt trap for foreign objects. It must be kept clean to avoid a reduction of the pumping speed. An anti-suck back valve is located inside the intake port to stop the oil from returning to the intake pipeline. It must be kept clean to prevent function failure leading the oil to return the intake pipeline.

For this purpose, remove the dirt trap and anti-suck back valve from the intake port and rinse them in a suitable vessel with solvent. Then thoroughly dry them with compressed air.

If the dirt trap is defective, replace it with a new one.

■ Note:

The cleaning intervals depend on the application. If the pump is exposed to large amounts of abrasive materials, a dust filter must be fitted into the intake line.



- 1. Screw
- 3. O-ring

- 2. Inlet port
- 4. Anti-suck back valve with O-ring

Tools required:

- Necessary tools to disassemble the customer intake hose or pipe if needed.
- Allen key 6 mm
- Plier

To clean the intake port dirt-trap do the procedure as follows:

- Disassemble the intake hose or pipe.
- Take out the wire-mesh screen and clean it using a suitable solvent.
- Use Allen key 6 mm to disassemble the intake port.
- Use a plier to take the anti-suck back valve out and clean it using a suitable solvent.
- Re-assemble the dirt trap in the reverse sequence.

Refer to Table: Inlet valve kit for more information.

8.3.6 Check the coupling and coupling element

A visual inspection for the presence of any damage needs to be done.

If the couplings are damaged, they must be replaced.

Check the edges of the teeth on the coupling element for any damages, change the coupling element as required.

Refer to *Table: Coupling unit kit* for more information.

8.3.7 Replacement of electrical motor




WARNING: DANGEROUS VOLTAGE

Risk of electric shock. Before starting work, must disconnect the motor from the power supply. Observe safety information given in *Electrical hazards* on page 10.

The motor can only be changed with an identical one from the same manufacturer and marking.

In case other motors are used, the pump loses its CE certification.



- 1. Nut
- 3. Motor flange
- 5. 7. Cooling fan
- Lock screw
- 9. Coupling (pump side)
- 11. Coupling (motor side)
- 13. Washer

- Electric motor
- 4. Screws of flange
- 6. Locking screw
- Coupling element 8.
- 10. Screw
- Snap ring

Required tools:

- Wrench 16 mm
- Internal snap ring plier
- Allen key 3 mm
- Allen key 4 mm
- Allen key 6 mm
- Possibly a puller for the coupling

To replace the motor do the procedure as follows:

- Disconnect the motor power supply.
- Disconnect the motor main connections.
- Remove the motor connection nuts with wrench 16 mm.
- Remove the motor from the coupling housing.

- Remove the coupling element.
- Remove the coupling with Allen key 3 mm.
- Use an internal snap ring plier to remove the snap ring.
- Remove the coupling with fan, use a puller if necessary.
- Disassemble the cooling fan from coupling using Allen key 4 mm if necessary.
- Disassemble the motor flange with Allen key 6 mm.
- Re-assemble the new motor in the reverse sequence.

8.3.8 Clean the motor cooling fan



WARNING: MAINTENANCE SAFETY

Risk of injury or damage to the equipment. Do not disassemble the motor cooling fan cover while the pump is in operation, shut down the pump first.

Tools required:

- Cross screwdriver
- Brush
- Industrial vacuum cleaner

To clean the motor cooling fan:

- 1. Shut down the pump.
- 2. Unscrew the motor fan cover.
- 3. Clean the motor cooling fan as required.
- 4. Reassemble the motor fan cover in the reverse sequence.

8.4 Service

8.4.1 Return the equipment or components for service

Before you send your equipment to us for service or for any other reason, you must complete a Declaration of Contamination Form. The form tells us if any substances found in the equipment are hazardous, which is important for the safety of our employees and all other people involved in the service of your equipment. The hazard information also lets us select the correct procedures to service your equipment.

If you are returning equipment note the following:

- If the equipment is configured to suit the application, make a record of the configuration before returning it. All replacement equipment will be supplied with default factory settings.
- Do not return equipment with accessories fitted. Remove all accessories and retain them for future use.
- The instruction in the returns procedure to drain all fluids does not apply to the lubricant in pump oil reservoirs.

Download the latest documents from *leybold.com/en/downloads/download-documents/declaration-of-contamination/*, follow the procedure in HS1, fill in the electronic HS2 form, print it, sign it, and return the signed copy to us.



NOTICE:

If we do not receive a completed form, your equipment cannot be serviced.

8.5 Spare parts

■ Note:

To guarantee the safe operation of the pump, use only original and genuine spare parts and accessories. When ordering spare parts and accessories, always state the pump type and serial number. You can find part numbers in the spare parts list.

The pump loses its CE certification if non-genuine parts are used.

Consumables and main spare parts kits for the pumps are usually available in stock at our service centres. The list of these parts is given hereafter and in the spare parts table where the contents of each kit are given in detail.

- Oils (Special oils refer to the specific notice of the pump or contact us)
- Shaft seal maintenance kit
- Major maintenance kit

We recommend using these kits which have been defined to allow optimal maintenance or repair. Individual spare parts may need a longer delivery time.

Table 7 Major maintenance kit

Part number	Part description	Remark
EK3002614150	Major maintenance kit for TRIVAC D 40 L	includes vanes, exhaust valves,
EK3002614151	Major maintenance kit for TRIVAC D 63 L	springs, bushings, shaft seals, O-rings, gaskets and other sealing
EK3002614152	Major maintenance kit for TRIVAC D 90 L	parts

Table 8 Gas ballast kit

Part number	Part description	Remark
GK6538488	LGAS DAIIAST KITTOR LBIVAG LL 40/63/90 L	includes gas ballast cap, body, screw and O-ring
GM6539427	Gas ballast cap (10 pcs)	

Table 9 Oil sight glass kit

Part number	Part description	Remark
GK6538266	Oil sight glass kit for TRIVAC D 40/63/90 L	includes oil sight glass, gasket and O-ring

Table 10 Coupling unit kit

Part number	Part description	Remark
GK6541321	Coupling unit kit for TRIVAC D 40/63 L	includes motor side coupling, cir- clip, jack screw, plastic element
GK6540642	Coupling unit kit for TRIVAC D 90 L	and pump side coupling
GM6539758	TRIVAC D 40/63/90 L coupling element (2 pcs)	-

Table 11 Inlet valve kit

Part number	Part description	Remark
GK88851240	Inlet valve kit for TRIVAC D 40/63/90 L	includes anti-suck back valve and O-ring
GM88836246	Inlet port O-ring (10 pcs)	

Table 12 Oil drain valve

Part number	Part description	Remark
G6545717	Oil drain valve TRIVAC D 40/63/90 L	-

Table 13 Motor

Part number	Motor description	Available for
E6535551	3-phase IE3 motor, 1.1 kW, EU/CN	1019040V00
G6535554	3-phase IE3 motor, 1.1 kW, EU/US/CN	1019040V01
G6535557	3-phase IE3 motor, 1.5 kW, JA/KO	1019040V02
E6535552	3-phase IE3 motor, 1.5 kW, EU/CN	1019063V00
G6535555	3-phase IE3 motor, 1.5 kW, EU/US/CN	1019063V01
G6535558	3-phase IE3 motor, 2.2 kW, JA/KO	1019063V02
E6535553	3-phase IE3 motor, 2.2 kW, EU/CN	1019090V00
G6535556	3-phase IE3 motor, 2.2 kW, EU/US/CN	1019090V01
G6535559	3-phase IE3 motor, 3 kW, JA/KO	1019090V02

Table 14 Spare part for accessories

Major maintenance kit	Description	Remarks
GK3002614101	Oil mist filter element TRIVAC D 40 L	
GK3002614102	Oil mist filter element TRIVAC D 60/90 L	-
GK3002614103	Seal kit for oil mist filter TRIVAC D 40 L	Includes O-ring, gasket and over- pressure valve
GK3002614104	Seal kit for oil mist filter TRIVAC D 60/90 L	Includes O-ring, gasket and over- pressure valve
GK3002614105	Oil return kit	Includes oil return pipe and connections
GM6547883	Seal plug for gas ballast hole (10 pcs)	
GM6549582	Seal plug for thermal switch hole (10 pcs)	_

9 Fault finding

Table 15. Fault finding

Condition
Pump does not start on page 62
Pump does not reach the ultimate pressure on page 62
Pumping speed is too low on page 63
After switching off the pump under vacuum, pressure in the system rises too fast on page 63
Pump gets too hot on page 63
Oil in the intake line or the vacuum vessel on page 64
Oil is turbid on page 64
Pump is excessively noisy on page 64
External oil leakage on page 65

Fault	Pump does not start	
Cause	Wiring malfunction.	
Remedy	Check and repair wiring.	
Cause	Motor protection switch incorrectly set (three-phase motors only).	
Remedy	Set motor protection switch properly.	
Cause	Motor is malfunctioning.	
Remedy	Replace the motor.	
Cause	The operating voltage does not match that of the motor.	
Remedy	Check whether the correct product number was booked. Adjust the voltage or replace the motor.	
Cause	Oil temperature is below 10 °C (50 °F)	
Remedy	Check the temperature with the team. Heat the pump and pump oil or use a different oil.	
Cause	Oil is too viscous.	
Remedy	Change the oil. Refer to Change the oil on page 54.	
Cause	Pump is seized.	
Remedy	Repair the pump. Contact Service.	

Fault	Pump does not reach the ultimate pressure	
Cause	Measuring technique or gauge is unsuitable.	
Remedy	Use correct measuring technique and gauge. Measure the pressure directly at the intake port of the pump.	
Cause	External leak	
Remedy	Repair the pump. Contact Service.	

Cause	The anti-suck back valve is malfunctioning.	
Remedy	Repair the valve. Refer to Clean the intake port dirt-trap and anti-suck back valve on page 56.	
Cause	Exhaust valve is malfunctioning.	
Remedy	Repair the valve. Contact Service.	
Cause	Oil is unsuitable.	
Remedy	Change the oil (degas it, if necessary). Refer to Change the oil on page 54.	
Cause	Vacuum lines are dirty.	
Remedy	Clean the vacuum lines.	
Cause	Pump is too small.	
Remedy	Check the process data, replace the pump if necessary.	

Fault	Pumping speed is too low	
Cause	The inlet screen in the intake port is clogged.	
Remedy	Clean the dirt-trap. Install a dust filter in an intake line to prevent clogging. Refer to Clean the intake port dirt-trap and anti-suck back valve on page 56.	
Cause	Connecting lines are too narrow or too long.	
Remedy	Use adequately wide and short connecting lines.	

Fault	After switching off the pump under vacuum, pressure in the system rises too fast	
Cause	System has a leak.	
Remedy	Check the system.	
Cause	Anti-suck back valve is malfunctioning.	
Remedy	Repair the valve. Refer to Clean the intake port dirt-trap and anti-suck back valve on page 56.	

Fault	Pump gets too hot	
Cause	Cooling air supply is obstructed.	
Remedy	Set pump up correctly.	
Cause	Ambient temperature is too high.	
Remedy	Set pump up correctly. Refer to .	
Cause	Process gas is too hot.	
Remedy	Change the process gas.	
Cause	Oil level is too low.	
Remedy	Add oil to reach the correct oil level. Refer to Check the oil level on page 53.	

Cause	Oil is unsuitable.	
Remedy	Change the oil. Refer to Check the oil condition on page 53.	
	Oil cycle is obstructed.	
Cause	Oil cycle is obstructed.	

Fault	Oil in the intake line or the vacuum vessel	
Cause	Oil comes from the vacuum system.	
Remedy	Check the vacuum system.	
Cause	Anti-suck back valve is obstruction.	
Remedy	Clean or repair the valve. Refer to <i>Clean the intake port dirt-trap and anti-suck back valve</i> on page 56.	
Cause	Sealing surfaces of anti-suck back valve is damaged or dirty.	
Remedy	Clean or repair the inlet port and the anti-suck back valve. Refer to <i>Clean the intake</i> port dirt-trap and anti-suck back valve on page 56.	
Cause	Oil level is too high.	
Remedy	Drain the excess oil. Refer to Check the oil level on page 53.	

Fault	Oil is turbid Condensation	
Cause		
Remedy	-Degas the oil or change the oil and clean the pump. Refer to <i>Change the oil</i> on page 54.	
	-To prevent condensation open the gas ballast valve or insert a condensate trap.	

Fault	Pump is excessively noisy	
Cause	Oil level is very low (Oil is no longer visible).	
Remedy	Add oil. Refer to <i>Check the oil level</i> on page 53.	
Cause	Silencing nozzle is clogged.	
Remedy	Clean or replace the silencing nozzle.	
Cause	Intake pressure is too high.	
Remedy	Lower the intake pressure.	
Cause	Coupling element is worn.	
Remedy	Install new coupling element. Refer to Check the coupling and coupling element on page 57.	
Cause	Vanes, bearings or other pump parts are damaged.	
Remedy	Repair the pump. Contact Service.	

Fault	External oil leakage	
Cause	Oil drain valve broken or thread loctite failed	
Remedy	Replace the oil drain valve or re-loctite the thread.	
Cause	Oil sight glass broken or sealing O-ring and gasket failed	
Remedy	Replace the oil sight glass kit.	
Cause	Oil casing sealing gasket failed or casing broken	
Remedy	Replace the oil casing sealing gaskets or replace the oil casing.	
Cause	Oil leakage at the shaft seals	
Remedy	Replace the shaft seals.	
Cause	Exhaust port blocked or the over-pressure valve thread loctite failed	
Remedy	Clear the exhaust line or re-loctite the valve thread.	
Cause	Plug seals failed or not fasten enough	
Remedy	Replace the plug seals or fasten the plugs.	

10 Accessories

Table 16. Accessories

Part description	Part number
Exhaust oil mist filter 40 m³/h	1019040A20
Exhaust oil mist filter 60-90 m³/h	1019090A20
Permanent GB kit with KF16 connection	A35924545
Solenoid GB kit with NW16	A35924546
Roots adapter	1019040A60

The stability of the pump is ensured with accessories supplied by us. Mounting of any other accessory will engage the responsibility of the user concerning the stability of the pump.

In case a direct roots pump coupling is used, it is important to check the gas temperature due to the roots compression.

10.1 Oil mist filter

Exhaust oil mist filters separate and trap the oil mist discharged with the exhaust gases from the pumps when gas-ballast is used or when very high gas throughputs are pumped. The exhaust oil mist filter traps oil mist with an efficiency of more than 99.97% at $0.3~\mu m$.

Part description	Part number
Exhaust oil mist filter 60-90 m³/hr	1019090A20

An oil return accessory kit is available for both kinds of exhaust oil mist filters to continuously return the trapped oil to the pump reservoir. Oil return kit is recommended to be used when the exhaust gases will not contaminate the pump oil.

Exhaust oil mist filter


Refer to Figure: Exhaust oil mist filter.

The exhaust oil mist filter has a carbon steel body with electrostatic powder coating. The filter element is made from glass-fibre.

The exhaust gases from the pump enter the inlet of the filter and then passes through the centre of the filter element.

The filter element separates and traps the oil mist. The trapped oil drains into the base of the mist filter. The oil-free exhaust gases are then discharged through the mist filter outlet.

The exhaust oil mist filter has a drain plug so that the trapped oil can be drained from the oil mist filter. The spring-loaded pressure relief valve prevents a dangerous pressure build-up inside the pump and the exhaust oil mist filter if the filter becomes blocked.



10.1.1 Technical data

Table 17. Technical data

Item	Specifications
Dimensions (mm)	210.5 x 187 x 236
Mass (kg)	2.7
Inlet port connection	KF40
Outlet port connection	KF40
Filter material	Glass fibre
Rated flow (m³/hr)	90
Ultimate pressure with oil return kits connected	9 x 10 ⁻³ mbar

10.1.2 Installation

Unpack and inspect

Check if your package contains the items shown in Table: Checklist of items. If any of the items is missing, notify your supplier in writing within three days.


If the accessory is not to be used immediately, return it to its protective packaging. Store the accessory in clean dry conditions, away from direct sources of heat and sunlight.

Table 18. Delivery scope


Material name	Quantity	Type/Specification
Oil mist filter	1	-
Connector of oil return kits to oil mist filter	1	G1/4" – Ø 4 mm ID
Connector of oil return kits to pump	1	G1/8" – Ø 4 mm ID
Pipe	1	1000 mm, ID 4 mm, OD 6 mm

Install the oil mist filter vertically (default)

- 1. Clean the area around the pump outlet.
- 2. Remove the silence plate as shown in figure. Please keep it for the future connection without oil mist filter or exhaust pipeline.




- 1. Silence plate
- 3. Install the centering ring with O-ring as shown below.




Centering ring with O-ring

4. Install oil mist filter as shown below.




Oil mist filter

5. Fit the swing clamp to attach adapter and oil mist filter.




- Swing clamp
- 6. Connect the oil return pipe to oil mist filter (with connector G1/4) and coupling housing (with connector G1/8).



- Connector G1/8
- 2. Connector G1/4
- Oil return pipe

7. The installation of vertical oil mist filter is completed.



10.1.3 Operation



WARNING: CONTAMINATION HAZARD

Risk of injury or damage to the equipment. If the oil is contaminated, the filter may become clogged. If the filter is clogged, the relief valve will open and oil mist will be discharged directly to the exhaust of the mist filter. You must replace the filter element if it becomes clogged.

- Check the oil level of the pump when you check the filter.
- Oil injection from outlet might occur during pump running due to oil accumulation, if the oil return kit is not installed. Oil return kit is recommended to be installed to return the oil back to pump in time..

10.2 Maintenance of oil mist filter



CAUTION: MAINTENANCE SAFETY

Risk of thermal hazard and oil mist inhalation hazard. When the pump is working the gas / oil mist inside will be over 60 °C and oil mist may come out from the exhaust port, you must switch off the pump to avoid hazard.

Please do weekly inspection as below, regular inspection will help to reduce failure happen and increase the service life.

- 1. Oil leakage around the connections
- 2. Smog from the exhaust oil mist filter outlet port
- 3. Strange noise

Refer to Fault finding of oil mist filter for solution.

Please exchange the oil mist filter element regularly or according to the application.

To exchange the oil mist filter element, you will need wrench 13mm and personal PPE and follow below precedure:

- 1. Switch off the pump.
- 2. Disconnect the oil mist filter exhaust port.
- 3. Cool down for at least 10 minutes.
- 4. Open the oil mist filter clamp, remove the cover.
- 5. Unscrew the over pressure screw using wrench 13mm.
- 6. Remove the old exhaust oil mist filter element.
- 7. Fit the new exhaust oil mist filter element.
- 8. Tighten the over pressure screw using wrench 13mm.
- 9. Fit the cover and lock the oil mist filter clamp.
- 10. Fit the oil mist filter exhaust port.
 Note: Sealing parts exchanging can follow above procedure.

10.2.1 Spare parts

Table 19. Spare parts

Part description	Part number
Oil mist filter element	GK3002614102
Seal kit for oil mist filter	GK3002614104
Oil return pipe	GK3002614105

10.2.2 Fault finding of oil mist filter

Fault	Smog from the exhaust port
Cause	Oil mist filter element failed or damaged.
Remedy	Exchange oil mist filter element.
Cause	Oil mist filter clogged.
Remedy	Exchange oil mist filter element.
Cause	Improper oil mist filter element position.
Remedy	Re-assemble the oil mist filter element.
Cause	High inlet pressure.
Remedy	Adjust inlet pressure.

Fault	Strange noise
Cause	Foreign objects in filter.
Remedy	Clean or exchange foreign objects.
Cause	Improper oil mist filter element position.
Remedy	Re-assemble the oil mist filter element.

Fault	Oil leakage
Cause	O-ring or gasket damaged.
Remedy	Replace sealing parts.
Cause	Improper oil mist filter element position.
Remedy	Re-assemble the oil mist filter element.
Cause	Oil mist filter element failed or damaged.
Remedy	Exchange oil mist filter element.
Cause	Oil mist filter connection failed.
Remedy	Re-assemble the oil mist filter.
Cause	Oil return pipe connection failed.
Remedy	Re-assemble the oil return pipe.
Cause	Oil return pipe damaged.
Remedy	Replace with seal kit.

Fault	Oil return failed
Cause	Oil retrun pipe clogged.
Remedy	Clean the pipes.
Cause	Pump oil path clogged.
Remedy	Repair the pump.

10.3 Solenoid valve for gas ballast

Automatic control of gas ballast can be achieved by solenoid valve for gas ballast.

Part description	Part number		
Solenoid GB kit with NW16	A35924546		

10.3.1 Technical data


Table 20. Technical data

Parameter	Values		
Supply voltage	d.c. 24 V		
Power consumption	12W		
Ambient temperature	-10 - 55 °C		

10.3.2 Installation

1. Disassemble the default gas ballast kit.

2. Install the solenoid valve gas ballast kit with default screws. Tighten the screws with socket head wrench 3mm.




- 1. Screw X 2 pieces
- Solenoid valve

10.3.3 Wiring connection

There are 3 terminals after cable plug removed, terminal 1 and 3 can be connect to "+" or "-" with following defined action.

Polarity	Specifications	Terminal connections		
- Switch ON +	Valve (P seat) will be opened	(+) on terminal 3, (-) on terminal 1		
+ Switch OFF - Valve (P seat) will be closed		(+) on terminal 1, (-) on terminal 3		



10.4 Permanent gas ballast


If there is no requirement of solenoid valve then we can install permanent gas ballast kit. We suggest permanent gas ballast should be connected with inert gas.

Part description	Part number		
Permanent gas ballast kit NW16	A35924545		

10.4.1 Installation

1. Disassemble the default gas ballast kit.

2. Install the permanent gas ballast kit with default screws. Tighten the screws with socket head wrench 3mm.



- Permanent gas ballast kit
- Screw X 2 pieces

Storage

11 Storage

- Before the pump is shelved it must be properly disconnected from the vacuum system, purged with dry nitrogen and the oil must be changed.
- The inlet and exhaust ports of the pump must be sealed with the shipping seals which are provided upon delivery.
- The gas ballast switch must be set to the "0" position.
- If the pump is to be shelved for a longer period it must be sealed in a plastic bag containing desiccant (silica gel).
- When a pump is put into operation after it has been shelved for over one year, standard maintenance of the pump must be done and the oil must also be changed (refer to Change the oil on page 54). We recommend that you contact us.
- Store the pump in a dry place at room temperature until the pump is put back into service again.
 - Storage temperature: -15 °C ~ 70°C
 - Storage humidity: less than 80% RH

Disposal

12 Disposal

Dispose of the pump, the oil and any components removed from the pump safely in accordance with all local and national safety and environmental requirements.

Particular care must be taken with components and waste oil that have been contaminated with dangerous process substances.



EU Declaration of Conformity

 ϵ

Leybold GmbH

Bonner Strasse 498 D-50968 Köln Germany Documentation Officer T: +49(0) 221 347 0 documentation@leybold.com

The product specified and listed below

Product: TRIVAC L - Two stage oil sealed rotary vane pumps with and without motor

Models: TRIVAC D 40 L, TRIVAC D 63 L, TRIVAC D 90 L

Pump family codes:

TRIVAC D 40 L: 1019040Vxy
 TRIVAC D 63 L: 1019063Vxy
 TRIVAC D 90 L: 1019090Vxy

Where

x can be 0 to 9 y can be 0 to 9 Defining their variants

xy = 03 = without motor (bare shaft - "BS" added to model name)

Is in conformity with the relevant requirements of European CE legislation:

2006/42/EC Machinery directive

Note: The safety objectives of the Low Voltage Directive 2014/35/EU were complied with in accordance

with Annex 1 No. 1.5.1 of this directive.

2014/30/EU* Electromagnetic compatibility (EMC) directive (electric motors are considered inherently benign in

terms of electromagnetic compatibility) Class A Emissions, Industrial Immunity

2011/65/EU Restriction of certain hazardous substances (RoHS) directive

as amended by Delegated Directive (EU) 2015/863

Based on the relevant requirements of harmonised standards:

EN ISO 12100:2010 Safety of machinery. General principles for design. Risk assessment and risk reduction

EN 1012-2:1996 +A1:2009 Compressors and vacuum pumps. Safety requirements. Vacuum pumps

EN 60204-1:2018* Safety of machinery. Electrical equipment of machines. General requirements

EN 61000-6-2:2005* Electromagnetic Compatibility (EMC) - Part 6-2: Generic Industrial Immunity Standard

EN 61000-6-4:2007* Electromagnetic Compatibility (EMC) - Part 6-4: Generic Industrial Emission Standard

This declaration, based on the requirements of the listed Directives and EN ISO/IEC 17050-1, covers all product serial numbers from this date on: 2022-02-16

You must retain the signed legal declaration for future reference

This declaration becomes invalid if modifications are made to the product without prior agreement.

Andries DE BOCK

VP Engineering - Industrial Vacuum Division

Cologne

Younsu Cho

General Manager of Leybold Tianjin Industrial Vacuum Division

^{*:} not valid for pump bareshaft versions without motor as indicated above





Declaration of Conformity

Leybold GmbHBonner Strasse 498
D-50968 Köln
Germany

Documentation Officer
Innovation Drive
Burgess Hill
West Sussex, RH15 9TW
documentation@leybold.com

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The product specified and listed below

- Product: TRIVAC L Two stage oil sealed rotary vane pumps with and without motor
- Models: TRIVAC D 40 L, TRIVAC D 63 L, TRIVAC D 90 L
- Pump family codes:

TRIVAC D 40 L: 1019040Vxy
 TRIVAC D 63 L: 1019063Vxy
 TRIVAC D 90 L: 1019090Vxy

Where

x can be 0 to 9 y can be 0 to 9 Defining their variants

xy = 03 = without motor (bare shaft – "BS" added to model name)

The object of the declaration described above is in conformity with relevant statutory requirements:

Supply of Machinery (Safety) Regulations 2008

The objectives of the Electrical Equipment (Safety) Regulations 2016 are governed by Annex 1 1.5.1 of this regulation.

Electromagnetic Compatibility Regulations 2016*

Class A Emissions, Industrial Immunity

Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

Relevant designated standards or technical specifications are as follows:

EN ISO 12100:2010 Safety of machinery. General principles for design. Risk assessment and risk reduction

EN 1012-2:1996 +A1:2009 Compressors and vacuum pumps. Safety requirements. Vacuum pumps

EN 60204-1:2018* Safety of machinery. Electrical equipment of machines. General requirements

EN 61000-6-2:2005* Electromagnetic Compatibility (EMC) - Part 6-2: Generic Industrial Immunity Standard

EN 61000-6-4:2007* Electromagnetic Compatibility (EMC) - Part 6-4: Generic Industrial Emission Standard

This declaration, based on the requirements of the listed Statutory Instruments and EN ISO/IEC 17050-1, covers all product serial numbers from this date on: 2022-02-16

You must retain the signed legal declaration for future reference

This declaration becomes invalid if modifications are made to the product without prior agreement.

Signed for and on behalf of Leybold GmbH

Andries DE BOCK

VP Engineering -Industrial Vacuum Division

Cologne

Younsu Cho

General Manager of Leybold Tianjin Industrial Vacuum Division

^{*:} not valid for pump bareshaft versions without motor as indicated above

ADDITIONAL LEGISLATION AND COMPLIANCE INFORMATION

EMC (EU, UK): Class A Industrial equipment

Caution: This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.

RoHS (EU, UK): Material Exemption Information

This product is compliant with the following Exemptions

Annex III:

- 6(b) **Lead** as an alloying element in aluminium containing up to 0.4% by weight
- 6(c) Copper alloy containing up to 4% lead by weight

REACH (EU, UK)

This product is a complex article which is not designed for intentional substance release. To the best of our knowledge the materials used comply with the requirements of REACH. The product manual provides information and instruction to ensure the safe storage, use, maintenance and disposal of the product including any substance based requirements.

Article 33.1 Declaration (EU, UK)

This product contains Candidate List Substances of Very High Concern above 0.1%ww by article as clarified under the 2015 European Court of Justice ruling in case C-106/14.

Lead (Pb)

This substance is present in certain aluminium / brass components.

Compliance Information – incorporated products and assemblies

Motors

2009/125/EC Ecodesign directive requirements for energy-related products Regulation (EU) No 2019/1781 electric motors and variable speed drives *Based in the requirements of harmonised standard:*

EN 60034-30:2009: Rotating electrical machines -- Part 30: Efficiency classes of single-

speed, three-phase, cage-induction motors (IE-code)

Additional Applicable Requirements

The product is in scope for and complies with the requirements of the following:

2012/19/EU

Directive on waste electrical and electronic equipment (WEEE)

材料成分声明

China Material Content Declaration

	有害物质 Hazardous Substances					
部件名称 Part name	铅 Lead (Pb)	汞 Mercury (Hg)	辐 镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr VI)	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
铜接头 Brass connectors	X	0	0	О	0	0
电机(泵和机械增压泵) Motors (pump and mechanical booster)	X	0	0	0	0	0

O: 表示该有害物质在该部件的所有均质材料中的含量低于 GB/T 26572 标准规定的限量要求。

X: Indicates that the hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T26572.

O: Indicates that the hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: 表示该有害物质在该部件的至少一种均质材料中的含量超出 GB/T26572 标准规定的限量要求。

